

Atom Ultra

Purifying Treatment for Atom Machine



Product Description

ATOM ULTRA is the purifying liquid specifically formulated to be used with Atom Machine, Errecom's ultrasonic nebuliser. Once inserted in Atom Machine, ATOM ULTRA saturates the room, purifying interiors, surfaces and A/C system ducts.

The main feature of the ultrasonic nebulisation system is to obtain nebulised liquid particles at room temperature, avoiding the condensation phenomenon that occurs when a liquid is nebulised by heating. The liquid particles nebulised with Atom Machine are smaller than 5 microns and are light enough to propagate completely in the A/C system, in the vehicle interior and on all the surfaces. This aim can't be achieved when common spray cans are used to sanitise A/C systems, passenger compartments, or interiors, because in those cases, the size and heaviness of the nebulised particles cause them to precipitate rapidly.

An ATOM MACHINE treatment cycle lasts 30 minutes. When the treatment is finished, the nebuliser will automatically switch off. The exposure time has been designed to ensure that a 20 m² room and all components of the A/C system are reached, letting the active substances enough time to saturate the room and ensure a high level of purification.

The 120 mL ATOM ULTRA treatment is available in different fragrances:

PURE, marine note;

LEMON, citrus note;

MINT, mentholated note;

SMOKI, which eliminates smoke and cigarette odours;

WOOFI, which eliminates pet odours.

NO ODOR, which eliminates all bad odours.

It's recommended to strictly observe the user guide enclosed with the Atom Machine.

Features

- Disinfectant registered in Germany (Reg. Nr. 91686).
- Refreshes and improves indoor air quality.
- Use only with ATOM MACHINE, Errecom's device.
- Purifies A/C system components and vehicle cockpits.
- Purifies rooms up to 20 sqm.

Vehicle Application

- 1 Insert ATOM ULTRA into ATOM MACHINE according to the instructions contained in the ATOM MACHINE manual and place the ultrasonic nebuliser on the passenger side mat, positioning the conveyor tube towards the air ducts.
- 2 Set the A/C temperature at 22°C and select front ventilation.
- 3 Switch on the recirculation mode.
- 4 Set ventilation to intermediate mode.
- 5 Open all air vents.
- 6 Switch ATOM MACHINE on, taking care to close doors and windows.
- 7 ATOM MACHINE will switch off automatically at the end of the treatment. Ventilate the passenger compartment for 5-10 minutes before entering.



Interior Application

- 1 Insert ATOM ULTRA into ATOM MACHINE according to the instructions contained in the ATOM MACHINE manual and place ATOM MACHINE in the room, far from delicate surfaces.
- 2 Switch ATOM MACHINE on, taking care to close doors and windows.
- 3 ATOM MACHINE will switch off automatically at the end of the treatment. Ventilate the room for 5-10 minutes before entering.



Available Packaging



Art.-Nr.	Description		
AB0018.G.01	120 mL Atom Ultra Lemon	12	-
AB0022.G.01	120 mL Atom Ultra Pure	12	-
AB0024.G.01	120 mL Atom Ultra Mint	12	-
AB0026.G.01	120 mL Atom Ultra Smoki	12	-
AB0027.G.01	120 mL Atom Ultra Woofi	12	-
AB0028.G.01	120 mL Atom Ultra No Odor	12	-



Art.-Nr.	Description		
VP1044.01	Atom Machine	01	-



Art.-Nr.	Description		
Atom Machine kit			
RK1393	Atom Machine + 48 bottles of Atom Ultra Lemon	01	48
RK1394	Atom Machine + 48 bottles of Atom Ultra Pure	01	48
RK1395	Atom Machine + 48 bottles of Atom Ultra Mint	01	48
RK1396	Atom Machine + 48 bottles of Atom Ultra Smoki	01	48
RK1397	Atom Machine + 48 bottles of Atom Ultra Woofi	01	48
RK1443	Atom Machine + 48 bottles of Atom Ultra No Odor	01	48



The packaging is made of cardboard, 100%.recycled.